hastings installation

Source One Handcrafted wallcovering is handmade and variations should be expected throughout the roll. Although extreme care is taken during manufacturing, variations in shade and texture are to be expected. Final inspections are the responsibility of the user. The installer should step back and examine the wallcovering after every few strips to ensure the desired effect is achieved.

CHECK BEFORE CUTTING Before cutting and hanging, check pattern name and number to match products ordered. NO CREDIT for labor charges will be allowed for cutting or hanging wrong colorways or patterns. Be sure that there is sufficient material to complete the job. Should you have any questions, contact your Source One distributor before proceeding. NO RETURNS will be accepted after the material is cut.

WALL PREPARATION Previous wallcovering must be removed. Walls must be structurally sound, dry, sealed and clean prior to installation. Wall surfaces shall be free from defects and imperfections that could show through the finished covered surface. Prime the walls with Kilz 2.

TRIMMING Handcrafted wallcoverings are usually cut into strips and dry trimmed. Take care to trim accurately. Be sure edges are even before installation. Each shipment contains bolts marked with consecutive numbers. This is the order in which the product was manufactured and should be followed in installation.

ADHESIVE You MUST use a quality grade of heavy-duty, premixed, clear vinyl adhesive with a low water content. DO NOT DILUTE. Using another type of adhesive will be solely at the risk of the installer. Source One Handcrafted wallcovering is not strippable or peelable. Apply an even coat of adhesive directly to the walls using a soft nap roller. Allow the adhesive to become tacky, then apply the wallcovering.

TEST HANGING Test hang three panels and carefully review materials and application. If satisfactory, continue the installation. If not, contact your Source One distributor. Neither Source One distribution or manufacturing assumes responsibility for the installation of material beyond three panels.

INSTALLATION Wallcovering shall be installed by experienced workers and contractors in strict accordance with these instructions. Material must be dry table trimmed. DO NOT DOUBLE CUT. Apply material to wall using a soft brush, plastic smoother or drywall blade wrapped with a soft cloth to lay out the material. When smoothing, work from the center out to the edges. To avoid trapping air bubbles, use an oval seam roller to butt seams. Wash smoothing brush and seam roller often, as an accumulation of paste on tools may mark or scratch the material. Completely clean adhesive off the surface after each strip is hung. Wash seams with a damp sponge and clean, warm water. Change rinse water often. Any adhesive left on the surface can cause flaking. Dry carefully with a soft cloth or chamois.

MAINTENANCE Stains can be removed when immediately wiped off with a clean sponge or rag (slightly damp). Use a mild detergent to clean the wallcovering. Do not soak. Avoid excess rubbing or pressure so as to not damage the finish.