

BOX (SLEEPER)

Zintra Baffles



Texture: 3 Lustre: 1

Transparency: 2

DESCRIPTION / FEATURES

Suspended box or sleeper-shaped baffles hung in perfectly spaced rows create these high performing baffles. The box shape feature not

only looks more substantial, it also increases the nrc rating by capturing sound within. Select the same shaped baffles or mix them up for added dimension.

Baresque's Zintra Acoustic Baffles are an innovative replacement to a mineral fibre lay system. Easy to assemble, easy to install and available in a large array of designs, baffles are ideally suited to large noisy spaces in educational institutions, shopping centres, restaurants and airports. Baffles use at least 1 sheet of Zintra Acoustic Panel and an NRC of 0.95.

Find out more about the Benefits of Zintra and its NRC rating on the DOWNLOAD tab.



HOW TO SPECIFY	1. Size
	2. Zintra Colour
	3. Mounting beam colour
COMPOSITION	Zintra Acoustic Panel - 100% Polyester
FINISHES AVAILABLE	Zintra Panel - Matt. Available in all 20 colours
	Square Tube 25mm x 25mm - Satin Aluminum or Black
STANDARD SIZE	4 STANDARD SUGGESTED ARRANGEMENT ARE
	AVAILABLE:
	RANDOM - 2400mm x 1000mm x 200mm
	MIXED - 2400mm x 1000mm x 200mm
	UNIFORMED LOW - 2400mm x 1000mm x 100mm
	UNIFORMED HIGH - 2400mm x 1000mm x 200mm
INDOOR/OUTDOOR	Indoor only
WET AREAS	No
SUGGESTED INSTALLATION	System supplied flat pack with Boxes already made up. See
	DOWNLOADS tab for install guide.
LEAD TIME	4-6 weeks
CUSTOMISABLE	Size - Yes
	Zintra Colour - Yes
	Square Tube Colour - Yes
	Contact Crown Surface Solutions for details
FIRE	Zintra
CARE INSTRUCTIONS	Zintra
ENVIRONMENTAL INFORMATION	Zintra
	1



FIRE RATING	In accordance with ASTM-E84, Zintra™ Acoustic 1/2" Panels
	achieve a Class A Flame Spread - passes CAN ULC S102-10.
ADDITIONAL COMMENTS	NDC 0.05
ADDITIONAL COMMENTS	NRC - 0.95
	Only available from Zintra Acoustic Panel 12mm.
	Baffle systems include Adjustable Cable Kit and Square Tube.
	See images on website for hardware detail.
	Longer Cables, multi-colour and Digital Print available for an
	additional fee.
SUPPLIED AS	Individual boxes (assembled), Square Tube, Adjustable Cable
	Kits.
	No screws included.
FABRICATION	Stanley knife if required



CARE INSTRUCTIONS	Remove spills immediately using damp, clean cloth.
	Dab Zintra with a clean, soft white cloth dampened with a mild
	solution of liquid detergent and warm water. Repeat using only
	clean water, then pat dry with a lint free cloth.
	Avoid using wax polishes, solvents or concentrated abrasives.
	For more difficult stains, dampen a soft white cloth with a solution
	of household bleach (10% bleach / 90% water). Dab gently.
	Repeat using only a clean, water dampened cloth to remove

Always test in an inconspicuous area first. If care instructions

don't deliver the expected results, cease cleaning method

bleach concentration, then pat dry with a lint free cloth.

immediately and contact Crown Surface Solutions for

assistance.



ENVIRONMENTAL INFORMATION Easily recycled through standard recycling channels
