

## PIXEL

Zintra Patterns



Texture: 3 Lustre: 1 Transparency: 1

DESCRIPTION / FEATURES The Zir	ntra popular acoustic solution has undergone a style
	and popular aboustio bolation has anaorgone a style
update	to bring you Zintra Patterns. Experience our range of
classic	to contemporary screen designs cut out of Zintra. The
perfora	ted panel can be installed as is or matching / contrasting
Zintra k	backer added to create a unique look for walls or ceilings.
In just t	the one product you will find style, texture, contrast, depth
and the	e added benefit of sound absorption to create a
harmor	nious environment.
* Increa	ased noise absorption
* Easy	installation
* Broad	range of neutral and bright colour
Find ou	It more about the Benefits of Zintra and its NRC rating on
the DO	WNLOAD tab.



HOW TO SPECIFY	1. Design
	2. Size
	3. Design Colour
	4. Backing Colour
COMPOSITION	Zintra Acoustic Panel - 100% Polyester
FINISHES AVAILABLE	Zintra Panel - Matt. Available in all 20 Zintra colours.
SHEET SIZE	610mm x 610mm
	1220mm x 610mm
	2745mm x 1220mm
	Pattern only - 12mm
	Pattern later on backer - 24mm
INDOOR/OUTDOOR	Indoor only
WET AREAS	No
SUGGESTED INSTALLATION	Check out the DOWNLOAD tab for a complete Handling and
	Installation guide.
	Be sure to support the panel during installation to avoid bowing or
	creasing.
	Adhere to substrate using contact adhesive, Liquid Nails or Z
	clips.
	Panel can also be mechanically fixed using details similar to
	glass fittings.



LEAD TIME	4-6 weeks.
CUSTOMISABLE	Design - Yes
	Colour - Yes
	Contact Crown Surface Solutions for details
THERMOFORMABLE	No
FIRE	Zintra
ADDITIONAL COMMENTS	Not suitable as a free standing product.
	NRC - 0.45 - 0.95
FABRICATION	Stanley knife if required
REFINISHABLE	No
CARE INSTRUCTIONS	Zintra
ENVIRONMENTAL INFORMATION	Easily recycled through standard recycling channels
FIRE RATING	In accordance with ASTM-E84, Zintra™ Acoustic 1/2" Panels
	achieve a Class A Flame Spread - passes CAN ULC S102-10.



SUPPLIED AS	Sheet ready to install
CARE INSTRUCTIONS	Remove spills immediately using damp, clean cloth.
	Dab Zintra with a clean, soft white cloth dampened with a mild solution of liquid detergent and warm water. Repeat using only clean water, then pat dry with a lint free cloth.
	Avoid using wax polishes, solvents or concentrated abrasives.
	For more difficult stains, dampen a soft white cloth with a solution of household bleach (10% bleach / 90% water). Dab gently. Repeat using only a clean, water dampened cloth to remove

bleach concentration, then pat dry with a lint free cloth.

Always test in an inconspicuous area first. If care instructions don't deliver the expected results, cease cleaning method immediately and contact Crown Surface Solutions for assistance.