



# ZINTRA CLOUDS

## TURBINE

### INSTALLATION INSTRUCTIONS



BOTTOM PERSPECTIVE



TOP PERSPECTIVE

# ZINTRA CLOUDS


## TURBINE

### INSTALLATION INSTRUCTIONS

## PARTS AND HARDWARE

ZINTRA CLOUDS - TURBINE

*PARTS WILL COME FLAT PACKED WITH A TOTAL OF 30 PARTS*



TOTAL PIECES: 30

P01: 4

P02: 26


(1) 1/4" - 20 HANGER BOLT (FOR USE WITH WOOD SUBSTRATE ONLY)



(1) ADJUSTABLE FASTENER




(1) CABLE WITH SWAGE END, AND BARREL




## YOU WILL NEED


SPIRIT LEVEL



DRILL



TAPE MEASURE



# ZINTRA CLOUDS

## TURBINE

### INSTALLATION INSTRUCTIONS


#### STEP 1

CHECK TO SEE IF PACKAGE CONTAINS ALL COMPONENTS. EVERY PART WILL COME WITH A NUMBER (FROM 1-2) TO REPRESENT THE CLOUD NUMBER.

THERE WILL BE A TOTAL OF 30 CLOUD PARTS:

P01: 4  
P02: 26


AND (1) OF EACH: HANGER BOLT, ADJUSTABLE FASTENER, CABLE WITH SWAGE END AND BARREL.



#### STEP 2

CONNECT P01 TOGETHER VIA THE 2 DOVE TAIL JOINTS (LOCATED ON OPPOSITE ENDS TO EACH OTHER).


NOTE: MAKE SURE THE TOP PANEL HAS THE 4 HOLES ON IT



#### STEP 3

CONNECT P02 PANEL TO P01 THROUGH THE SLOT THAT DOVE TAIL JOINT CREATES (SHOWN IN B).

**MAKE SURE THE CLOUD PIECE IS COVERING THE DOVE TAIL JOINT**




# ZINTRA CLOUDS TURBINE INSTALLATION INSTRUCTIONS

## STEP 4


REPEAT STEP 2 AND STEP 3  
TO CREATE THE FOUNDATION  
FOR THE TURBINE ASSEMBLY.

ALL DOVETAIL JOINTS AND  
SUPPORT CLOUDS (P01) SHOULD  
BE ASSEMBLED AT THIS POINT



## STEP 5


CONTINUE TO FILL ALL THE SLOTS WITH  
P02 TO CREATE THE STRUCTURE SHOWN



## STEP 6

LOCATE THE MIDPOINT FOR WHERE  
THE 4-WAY A.S.K WILL BE LOCATED.

DIMENSIONS OF WHERE THE MIDPOINT  
IS SHOWN IN THE DIAGRAM.




# ZINTRA CLOUDS

## TURBINE

### INSTALLATION INSTRUCTIONS

#### STEP 7

AFTER IDENTIFYING EACH CORRESPONDING POINT ON THE CEILING SUBSTRATE, TO THE POINTS MARKED ON STEP 7, DRILL AND ATTACH 1/4"-20 DOUBLE SIDED HANGER BOLT TO SUBSTRATE. REFERENCE DETAIL (SUPPLIED FOR WOOD ANCHORING ONLY). FOR ALL OTHER SUBSTRATES, STUDS/ ANCHORS MUST BE SOURCED BY THE INSTALLER.




#### STEP 8

A. IDENTIFY THE THREADED END OF THE BARREL AND THE SWAGE END OF THE WIRE.

B. INSERT THE PLAIN END OF THE SUPPLIED WIRE THROUGH THE LARGE THREADED END OF THE BARREL UNTIL THE SWAGE END IS SEATED IN THE BARREL.


C. ATTACH THE THREADED END OF THE BARREL TO 1 / 4"-20 HANGER BOLT.



#### STEP 9

LOOP THE WIRE THROUGH THE 4 HOLES ON THE TOP OF P01.

MAKE SURE THE WIRES MEET AT THE MIDPOINT




# ZINTRA CLOUDS TURBINE INSTALLATION INSTRUCTIONS

## STEP 10

A. INSERT THE PLAIN END OF THE SUPPLIED WIRE THROUGH ONE SIDE OF THE ADJUSTABLE FASTENERS.

B. LOOP THE WIRE AROUND THE CROSSRUNNER WHERE MARKED.

C. RE-INSERT THE PLAIN END OF THE WIRE INTO THE REMAINING SIDE OF THE ADJUSTABLE FASTENER UNTIL SECURE.



## STEP 11

ONCE THE HANGING KIT IS PROPERLY SUSPENDED, TRIM THE EXCESS WIRE (IF NECESSARY) WITH WIRE CUTTERS.

**NOTE: WIRE IS INFINITELY ADJUSTABLE BY DEPRESSING TAB ON APPROPRIATE SIDE.**

